



## Parts and Materials

Item	Description	Material
1	Body	SS A479-316
2	Lift Lever Bonnet	SS A479-316
3	Cap	SS A479-316
4	Spring Washer	SS A479-316
5	Adjusting Screw	SS A479-316
6	Hex Jam Nut	SS 316
7	Spring	Inconel <sup>®</sup> X750
8	Spindle	SS 17-4
9	Disc	SS 17-4
10	Nozzle	SS 17-4
11	Nozzle Seal	GRAFOL <sup>®</sup> /SST
12	Reseat Seat	SS 17-4
13	Spacer	SS A479-316
14	Cage Guide	SS A479-316
15	Reseat Piston	SS 17-4
16	Blowdown Adjustment Bushing	SS A479-316
17	Thread Seal	GRAFOL <sup>®</sup>
18	Blowdown Adjustment Nut	SS A479-316
19	Blowdown Adjustment Packing	GRAFOL <sup>®</sup>
20	Safety Lock Screw	SS 18-8
21	Blowdown Adjustment Screw	SS A479-316
22	1/2 NPT Pipe Plug	SS A479-316
23	Vent	Aluminum
24	Shim	SS 316
25	Lever	SS 316
26	Torsion Spring	SS 316
27	O-ring	Teflon <sup>®</sup>
28	Lock Washer	SS 18-8
29	Roll Pin	SS 420
30	1/4-28 x 1/4 Bolt	SS 18-8
31	Cam	SS 316
32	Gland Nut	SS A479-316
33	Gag Rod	Stainless
34	Gag Rod Lever	SS 18-8
35	Bolt	SS A193-B8M
36	Ball	SS 440C
37	Disc Spring Washer	ALYMP35N <sup>®</sup>
38	Bonnet Spring Washer	SS 17-4
39	Adjustment Screw Retainer	SS 17-4
40	Stop Pin	SS 18-8
41	Packing Retainer	SS 316
42	Blowdown Adjustment Sleeve	SS 17-4


## Optional Features



Threaded Cap



Threaded Cap and Gag



Lift Lever and Gag